Instrument Front Panel Illustration

Never place an OPERATING coil within 2 yards of this machine or other sensitive electronic equipment (such as a tv set). The magnetic field of the coil may damage electronic equipment.

THE CAPACITOR SWITCHES (INCLUDING THE CAPACITOR BYPASS SWITCH) CAN BE SWITCHED ON OR OFF ONLY WHEN THE CURRENT METER SHOWS NO CURRENT. (THE SWITCHES AND CAPACITORS WILL BE DAMAGED OTHERWISE.)

